superbrightleds.com

User Manual

JTS-JK-FS

Important: Read all instructions prior to installation.

2007-2017 Jeep Wrangler JK Fender Flare Turn Signals

Included Parts

(2) Jeep Wrangler JK Fender Flare Turn Signal Lamps

Specifications

Fitment	2007-2017 Jeep Wrangler JK
Operating Voltage	12 VDC
IP Rating	IP67 waterproof
Warranty	2-year

Pre Installation Instructions

1. Read all safety notes and mounting guidelines before installing the product.
2. Verify that all parts are present and complete.
3. Verify that all power supply and charging systems comply with the specified voltage limits for the light.
4. Turn off the vehicle and disconnect the battery.

Installation Instructions

Required Tools[1]

- Automotive clip removal tool or trim tool
- Socket wrench with 10 mm socket
- Pick tool or small flat head screw driver

Pro Tips: Retain all screws and trim clips in a safe location for reinstallation. For better access turn your wheels in the direction of the side you are working on.

1. Use the 10 mm socket to remove the forwardmost 10 mm screw from the fender liner. Use the clip or trim removal tool to remove the two (2) forwardmost plastic trim clips and pull back the fender liner.

2. Release the locking tab on the wire harness connector and remove the plug from the stock turn signal.

3. Press the locking tab on the turn signal housing (Fig. 1) and remove the turn signal lamp from the fender.

4. Take the LED turn signal lamp that corresponds to the one you removed (R or L) and install it in the fender using the guide and locking tabs.

Fig 1.

[1]Note that required tools may vary by model and trim level. Subject to change without notice.

4400 Earth City Expy, St. Louis, MO 63045 • 866-590-3533 • superbrightleds.com

Important: Read all instructions prior to installation.

2007-2017 Jeep Wrangler JK Fender Flare Turn Signals

Instructions Cont.

5. Plug the wire harness into the turn signal lamp socket.

6. Repeat steps 1-5 for the other turn signal.

7. Reconnect the battery and apply power to test functionality.

8. Replace the fender liners and secure with trim clips and 10 mm screws to complete installation.