

# **User Manual**

Important: Read all instructions prior to installation.

#### **WSR-LRR**

# **LED-Ready Mini Wall Sconce**




### **Safety and Notes**

- Product should be installed and serviced in accordance with applicable national, state, and local building and electrical codes.
- To reduce the risk of electric shock, ensure that the main power source and circuit breakers are switched off before performing any installation or wiring procedures.
- · Avoid looking directly into lamp when illuminated.
- Ensure all mounts are securely attached and will support the weight of the fixture.
  Failure to properly support fixture may result in damage or injury, for which the manufacturer does not assume responsibility.
- · Connect to voltage corresponding to the bulb used with the fixture.

## **Wiring Diagram**

Low Voltage Connection



### **Specifications**

Model	WSR-LRR
Compatible Bulb Type	MR16 (GU5.3 base)
Environmental Rating	Suitable for wet locations

### Installation

- 1. Remove supply power from circuit.
- 2. Remove the two nuts holding the mounting plate to the light.
- 3. Run wiring through strain relief and connect to terminal block.
- 4. Attach mounting plate to desired surface.
- 5. Reattach light to mounting plate.
- 6. Unscrew lens and install compatible bulb.
- 7. Reattach lens.
- 8. Restore supply power.

