

Important: Read all instructions prior to installation.

Rechargeable LED Road Flare



Included Parts

Single Pack Included Parts

- 1 - Rechargeable LED Road Flare
- 1 - Magnetic Charging Dock
- 1 - USB Charging Cable
- 1 - 12V Car Charger USB Adapter
- 1 - USB Wall Adapter

6-Pack Included Parts

- 6 - Rechargeable LED Road Flare
- 1 - Magnetic Charging/Carrying Case
- 1 - 12V Car Charger
- 1 - Wall Charger

Specifications

SF-x16R	
Charge Time	6 Hours
Run-Time (full charge)	2.5 ~ 60 Hours
Operating Temperature	-4°~122° F (-20°~50° C)
IP Rating	IP65

Operating Modes

To turn on flare, use the ON/OFF switch located on top of the flare. Cycle operating modes by pressing the ON/OFF switch when flare is on. Hold the ON/OFF switch for approximately 2 seconds to turn off the flare.

Flare Operating Modes		
Button Cycle	Effect	Run-Time (full charge)
Press 1x	Rotate	6 Hours
Press 2x	Quad-Flash	14 Hours
Press 3x	Single-Blink	60 Hours
Press 4x	Alternate	3 Hours
Press 5x	Morse Code / SOS	4 Hours
Press 6x	Solid-On (low)	32 Hours
Press 7x	Solid-On (high)	2.5 Hours
Press 8x	2 LED Flashlight	12 Hours
Press 9x	4 LED Flashlight	6.5 Hours
Press 10x	Turn Off	N/A

Battery Charge Indicator

To show battery capacity, hold ON/OFF button for 6 seconds. Flare displays remaining battery life by illuminating a percentage of the flare.

- 14–16 LEDs on, battery is fully charged
- 8 LEDs on, battery is at 50%
- 2 LEDs on, battery needs recharging

Note: Takes approximately 6 hours to charge when battery is completely dead.

Recharging Instructions

Single Pack Charging

1. Attach magnetic charging dock to LED road flare making sure to match polarity (+ to + and - to -) on charging contacts.
2. Connect to power source using one of the following options.
 - Connect USB cable to USB port on computer or other device.
 - Connect USB cable to wall adapter (120 VAC input).
 - Connect USB cable to car charger adapter (12 VDC input).
3. When charging, indicator light on magnetic charging dock turns red. When fully charged, indicator turns green.

6-Pack Included Parts

1. Insert LED road flare(s) into case, making sure to match polarity (+ to + and - to -) on charging contacts.
2. Connect case to power source using one of the following options.
 - Connect to wall adapter (120 VAC input).
 - Connect to car charger adapter (12 VDC input).
3. When charging, indicator light(s) on magnetic charging dock turn red. When fully charged, indicator(s) turn green.

