

Important: Read all instructions prior to installation.

Off-Road Rock Light Kit



Safety and Notes

- To reduce the risk of electric shock, ensure that the main power source is disconnected/off before performing any installation or wiring procedures.
- Avoid looking directly into lamp when illuminated.
- Ensure all mounts are securely attached. Failure to properly attach lights may result in damage or injury, for which the manufacturer does not assume responsibility.

Specifications


Specifications	
Operating Temperature	-4°–122° F (-20°–50° C)
IP Rating	IP68 (submersible up to 2 m)
Input Voltage	9–32 VDC

Installation



Warning: Before making any connections to the automotive wiring, always disconnect the battery negative terminal

1. Disconnect negative battery terminal.
2. Mark the drill hole locations using the rock light as a template.
3. Mount rock lights and Bluetooth controller, routing switch to an easily accessible location.
4. Connect lights to harness and connect supply wiring to battery power.




RLMK-RGBW12-4 shown



Locking Remote

The remote can be locked so that it only communicates with one controller. By default, any remote will work with any RLMK kit. To lock the remote press and hold the orange lock button for five seconds. To unlock, press and hold the yellow unlock button for five seconds.



Rev Date: V1 04/26/2023

4400 Earth City Expy, St. Louis, MO 63045 • 866-590-3533 • superbrightleds.com

Important: Read all instructions prior to installation.

Off-Road Rock Light Kit


App Instructions

Download and install the HappyLighting app on a Bluetooth enabled smart device. Follow the instructions in the app to connect it to the light kit.

Apple




Android




Group Manage

Manage devices and light groups, connect and confirm connection was successful, and rename devices here.




Color Selection

Select custom colors using the color circle. Use the brightness slider to increase and decrease intensity. Preset colors are frequently used selections, while standard colors are app default selections. Tap the background icon to select a background from photos from your device.




Settings

Tap the gear icon to reach the settings. Toggle the shake feature on/off here or change the background image.




Music and Tape

Use music or the microphone to make the light change according to sound. Use the slider to adjust microphone sensitivity in Tape mode.



Style

Select preprogrammed color modes and adjust speed of each color mode.



Timing

Timing interface for alarm setup and toggling. When countdown is reached, LEDs will turn ON or OFF.