

**User Manual** 

**RSL-Series** 

Important: Read all instructions prior to installation.

# **Recessed LED Step Lights**

#### **Included Parts**

- 1 step light
- 1 wire pigtail

### **Safety and Notes**

- This product should be installed and serviced in accordance with applicable national, state, and local building and electrical codes.
- To reduce the risk of electric shock, ensure that the main power source and circuit breakers are switched off before performing any installation or wiring procedures..
- When interconnected, each six light accessory harness will support five lights each instead of six as the last connector will be used to connect to the next harness.



## **Specifications**

Model	RSL-x
Operating Temperature	-4°-122° F (-20°-50° C)
IP Rating	IP65

## **Optional Accessories**


RSL-6S - six light wire harness for single color light
RSL-S2M - 6.6 ft (2 m) extension harness for single color light
RSL-6RGB - six light wire harness for RGB lights
RSL-RGB3M - 9.8 ft (3 m) extension harness for single RGB
light


#### Installation

- 1. Mark and drill 5/8" hole in mounting surface.
- 2. Make electrical connection
- Test fit light. If needed, apply silicone adhesive to assist in securing light.

## **Dimensional Drawings**

#### RSL-40K1-S shown (dimensions represent all models)















**User Manual** 


**RSL-Series** 

Important: Read all instructions prior to installation.

# **Recessed LED Step Lights**

## **Dimensional Drawings (accessories)**

#### RSL-6RGB (Dimensions also represent RSL-6S)



#### RSL-RGB3M

#### 1.39in 1.42in [35.39mm] [36.07mm] 117.19in [2976.62mm] 10ft [3048mm]

#### RSL-S2M

