## **User Manual**

Important: Read all instructions prior to installation.

#### **TPLF Series**

## Tri-Proof LED Shop Light

TPLF-xK4-60

#### **Included Parts**

- 1 tri-proof LED fixture
- 2 mounting bracket
- 2 M3.5 x 40 mm retaining screw
- 4 M4 x 30mm Phillips screw
- 4 plastic anchor


#### **Specifications**

Model	TPLF-xKx-x
Operating Voltage Range	100–277 VAC
Beam Angle	180 degree
Operating Temperature	-4–122° F (-20–50° C)
IP Rating	IP65

#### **Safety and Notes**

- Product should be installed by a certified electrician in accordance with applicable national, state, and local building and electrical codes.
- To reduce the risk of electric shock, ensure that main power source and circuit breakers are switched off before performing any installation or wiring procedures.
- Avoid looking directly into lamp when illuminated.
- Ensure all mounts are securely attached and will support weight of the fixture. Failure to properly support the fixture may result in damage or injury, for which the manufacturer does not assume responsibility

#### Wiring Diagram




### **Optional Accessories**

TPLF-HKO - suspension hanging kit



515PV - 5-15P electrical plug WP18-35J - 18 ga jacketed three conductor power wire






Drill two pairs 15/64" holes on the ceiling or wall. These 1. should be spaced as indicated in provided application table for length and 1" to 1 1/16" apart to accommodate bracket.


Model	Recommended Mounting Hole Distance
TPLF-xK2-x	16–20 in. (0.4–0.5 m)
TPLF-xK4-x	36-44 in. (0.9-1.1 m)

Insert plastic anchor into the hole and secure the bracket with 2 M4 screws provided.



3. Attach the light to the brackets and secure with locking screws provided.





Rev Date: V2 04/04/2021 4400 Earth City Expy, St. Louis, MO 63045 866-590-3533

superbrightleds.com

# superbrightleds.com


## User Manual

**TPLF Series** 

Important: Read all instructions prior to installation.

## **Tri-Proof LED Shop Light**

#### Suspension Installation (Optional TPLF-HKO Required)



#### Suspended Hanging Installation

1. Drill two pairs 15/64" holes on the ceiling or wall. These should be spaced as indicated in provided application table for length and 1" to 1 1/16" apart to accommodate bracket.

Recommended Mounting Hole Distance
16–20 in. (0.4–0.5 m)
36-44 in. (0.9-1.1 m)

- 2. Insert plastic anchor into hole and secure hanging wire mount with M4x30mm screws provided.
- 3. Attach mounting bracket to hanging wire nut with M4 flat washer and M4x8 mm screw provided.
- 4. Attach fixture to mounting bracket using provided screws.

