




Instruction includes methods of montage:



2) Rod - non-conductive (drop lead)





Tools needed for mounting:

- drill
- pliers
- allen wrench
- soldering iron

NOTE! All LED strips must be connected to a 12 V or 24 V power supply.

IMPORTANT: The manual presents the simplest mounting procedure.

More mounting procedures and related accessories can be found at klusdesign.com

www.KlusDesign.com 1



45-ALU - suspended fixture mounting instructions 1. Rod - conductive driven power supply

*If fully built fixtures are ordered and received from KLUS please skip to #4

1. Drill a holes with a diameter of 5 mm in the selected extrusion to lead the power cable.




Fi 5 mm

bottom view




3. Mount the LED strip in the extrusion and lead the cables through pre-drilled smaller holes. Then lead them to the connector sof the DP-45-MOC-ZZ fasteners. Each hole should lead a cable with one power pole, LED strip has to be cut before installation, so the wires can be easily routed to the holes.




5. Install the W-KG-Z ceiling fasteners. The fastener installation manual can be downloaded at www.klusdesign.com. Connect the cables, each for the single power pole to the fasteners. The cables should go through a pre-drilled hole just under the masking cover of the fastener.







4. Install the rod, cover and both end caps.



6. Mount the fixture with rods into the ceiling fasteners. Mind that the power poles connected to the rods should match the ones connected to the fasteners.





www.KlusDesign.com 2



45-ALU - suspended fixture mounting instructions 2. Rod - non conductive (requires drop lead)

*If fully built fixtures are ordered and received from KLUS please skip to #4

1. Drill a holes with a diameter of 5 mm in the selected extrusion to lead the power cable.



Fi 5 mm





2. Insert the extrusion into the mounting bracket of the head. Manual for the DP-45-MOC fastener can be downloaded from www.klusdesign.com.




3. Mount the LED strip in the extrusion and lead the cable through a pre-drilled












downloaded at www.klusdesign.com. Place the power supplier next to the fastener and drill the ceiling to lead the cable to it.







www.KlusDesign.com 3