

Important: Read all instructions prior to installation.

LED Power Supply



Safety and Notes

- Product should be installed and serviced by a certified electrician in accordance with applicable national, state, and local building and electrical codes.
- To reduce the risk of electric shock, ensure that the main power source and circuit breakers are switched off before performing any installation or wiring procedures.
- Ensure all mounts are securely attached and will support the weight of the power supply. Failure to properly support may result in damage or injury, for which the manufacturer does not assume responsibility.
- Installation of over-voltage protection and surge protection devices in the power supply circuit of lamps is recommended to ensure safety during use.
- When adjusting the output current of the power supply, please ensure that the total output power does not exceed the rated Max. power as this will void the warranty.
- Do not install in completely sealed enclosures. Enclosures must be ventilated with holes to allow air passage.
- Suitable for wet locations. Do not expose to corrosive gas or liquids.
- **Ensure the installation of the power supply complies with all driver specifications.**

Specifications

Environmental Specifications	
Operating Temperature	-4°–122° F (-20°–50° C)
IP Rating	IP65

Check product label for specific electrical specifications related to installation.
Improper installation will void warranty.

Installation

1. Install the driver firmly onto the lamp bracket with suitable screws.
2. Make all wiring connections and briefly apply power to test for proper function.
Once proper operation is confirmed, remove power again and complete installation.
3. Ensure heat dissipation is appropriately addressed within the fixture and that all wiring connections are airtight and waterproof.
Only after these requirements are sufficiently met can the driver be operated.
4. If any event occurs, such as tripping or irregular operation, disconnect the power main and the connection to the luminaire before investigating the problem. If the driver is found to be defective, please get in touch with customer support for resolution.

Wiring Diagram

