

**Important: Read all instructions prior to installation.**


## Selectable CCT Linear LED Strip Light




LSFD-SW3C40W-H

### Wiring Diagram

#### 120–277 VAC Input



#### 0–10 V Dimming




### Safety and Notes

- Product should be installed in accordance with applicable national, state, and local building and electrical codes.
- To reduce the risk of electric shock, ensure that the main power source and circuit breakers are switched off before performing any installation or wiring procedures.
- Avoid looking directly into the lamp when illuminated.
- Ensure all mounts are securely attached and will support the weight of the fixture.
- Failure to properly support the fixture may result in damage or injury, for which the manufacturer does not assume responsibility.

Check product label for specific electrical specifications related to installation.  
Improper installation will void warranty.




### CCT Selection

Use CCT selection switch to adjust CCT setting.



### Installation Instructions (surface mount)

1. Measure and drill holes in mounting surface.
2. Remove diffuser lens using the releases pictured to the right.
3. Attach mounting plate. With supply power off, connect wiring.  
Note: Conduit can be directly attached to mounting plate.
4. Securely mount fixture.
5. Reinstall diffuser lens.
6. Select desired CCT value using switch.



Rev Date: V0.1 11/05/2020

4400 Earth City Expy, St. Louis, MO 63045

• 866-590-3533

• [superbrightleds.com](http://superbrightleds.com)

**Important:** Read all instructions prior to installation.

## Selectable CCT Linear LED Strip Light

### Installation Instructions (optional hanging kit LSFD-HK)

1. Measure and drill appropriate holes in ceiling and install hooks (not included) if needed.
2. Attach cables to ceiling hooks or wrap around suitable pipe or beam.
3. Attach triangular hangers to cables, then hang light on them.
4. With supply power off, connect wiring.
5. Adjust CCT using switch on the side of fixture.

